






DMX EP-TOUCH-2 CONTROLLER



EPIC Controller presents the Dimmer switch of the 21st century



As simple as a dimmer switch

3 touch sensitive buttons

Glass wall-mounted DMX controller

Micro-usb for programming

Customized design for OEM

For PC, MAC & Tablet with USB

32bit ARM technology

86x86x10mm size

Software included

Stand alone operation

Ready to use (pre-loaded)

128 DMX channels



Windows



Mac



Tablet




DMX EP-TOUCH-2 CONTROLLER

the most simple
glass touch DMX controller

the most powerful
lighting software bundle

the industry standard
for RGB, LED, DMX lighting




ON/OFF
Short Touch
Easy switch
on and off

CHANGE MODE
Touch and hold
To change between color,
scene and dimmer mode




Scene



Scene 2/8

Yellow

Color



Pressing previous and next
simultaneously will reset dimmer/color

COLOR MODE


Holding the left or right button allows for direct access to any color. A single touch gives access to the basic colors. Pressing the 2 arrows at the same time will return to the default color.

SCENE MODE

The left and right buttons allow you to change the current scene. A scene can be static (one step) or dynamic (several steps with fade/hold time)

Dimmer

65%



DIMMER MODE

The left and right buttons can be used to change the brightness. Pressing the 2 arrows simultaneously will reset to the default level.

